

HELLER

4 Slice Sandwich Press

User Manual

Model Number: SP04



READ AND SAVE THESE INSTRUCTIONS

IMPORTANT

Read and follow the instructions in this user manual even if you feel you are familiar with the product, and find a place to keep it handy for future reference.

For your convenience record the complete model number (located on the product identification plate) and the date you received the product, together with your purchase receipt and attach to the warranty and service information. Retain in the event that warranty service is required.

NOTE: The rating of this product (as marked on the product identification plate) is based on specific loading tests. Normal use or the use of other recommended attachments may draw significantly less power.

IMPORTANT SAFEGUARDS

When using any electrically powered product, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT

WARNING! - to reduce the risk of fire, electrical shock or injury to persons or property:

- Carefully read all instructions before operating your new product for the first time and save for future reference.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the plug of this appliance.
- Ensure the Sandwich Press is properly assembled before use. Follow the instructions provided in this manual.
- Do not place the Sandwich Press near the edge of a bench or table during operation. Ensure the power cord does not hang over the edge of the bench or table, touch hot surfaces or become knotted.
- Do not place the Sandwich Press on or near a hot gas or electric burner, or where it could touch a heated oven. Do not use the Sandwich Press on a sink or drain board.
- Never operate the appliance with wet hands.
- Ensure the Sandwich Press is placed at least 20cm from walls, curtains and other heat sensitive and flammable materials. Always operate the Sandwich Press on a flat, even, heat resistant surface.
- This Sandwich Press is not intended to be operated by means of an external timer or separate remote control system.
- Do not place anything on top of the Sandwich Press when the lid is closed, when operating or when stored.
- Always pull the plug from the socket, when not use it or when cleaning the appliance. Always pull the plug, not the cable.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.
- This appliance contains no user serviceable parts. Any maintenance other than cleaning should be performed by a qualified person.
- Do not immerse unit, power plug or power cord in water, or any other liquid.

- Never operate any appliance with a damaged power cord or plug, should the appliance malfunction, or if it has been damaged in any manner.
- Do not leave the appliance unattended whilst it is on.
- Always operate the appliance on an even surface. Make sure that there is enough ventilation, so that the hot steam can disappear.
- During operation, the outer surface will be hot. Please do not touch outer surface by you hand.
- Before connecting with supplier mains, the heating plates must be in a closed position.

FEATURES



1. Non-Stick Cooking Plates
2. Warm Up light- Red
3. Ready light- Green
4. Floating Hinged Top Plate

5. Locking Storage Clip
6. Cord Storage

BEFORE FIRST USE

- Carefully remove your Sandwich Press from the box and remove any packaging materials.
- Wipe over the cooking plates with a damp cloth or sponge.
- Fully unwind the power cord.

INSTRUCTIONS

1. Place the Sandwich Press on a flat, level surface, with the lid closed. Press the 'Unlock' storage clip, this will unlock the cooking plates.
2. Insert the plug into a power outlet, and turn the power on. The red 'Warm up' indicator light will illuminate.
3. Allow the Sandwich Press to preheat (keep the lid closed) until the green 'Ready' indicator light illuminates (it will take about 4 minutes).

NOTE: For the first use only, season the cooking plates by applying a thin coat of cooking oil, butter, or margarine and rub it with a paper towel. Be careful, as the plates will be hot.

4. Open the appliance and place your sandwich on the lower plate. Always place the sandwich toward the rear end of the plate. Close the upper plate. Do not force the lid down, the floating design should evenly press down on the sandwiches.
5. Depending on the thickness of your sandwich, toasting should only take a few minutes (3 – 8 minutes), depending on personal taste and the type of bread and fillings used.



WARNING: When the lid is closed, steam will escape from inside the Sandwich Press. Be careful not to come in contact with the steam, as it can cause burns.

NOTE: the green 'Ready' indicator light will cycle on and off during toasting. This indicates that the correct temperature is being maintained.

6. When your toasted sandwich is cooked, remove it with the help of a plastic or wooden spatula. Never use metal utensils to remove the sandwich, as it can damage the non-stick coating.
7. After using, pull out the plug and open the upper lid let it get cool. If you are making another toasted sandwich, keep the lid closed until you are ready, this maintains the temperature.

HANDY HINTS

- This Sandwich Press is designed for regular sized bread. Most types of breads can be used, but when using sweet breads, keep in mind that they will brown faster due to the high sugar content.
- Do not overfill your toasted sandwich, and allow the sandwich to cool slightly before eating, as most fillings retain heat and can cause burns if eaten too quickly.
- Even though the cooking plates are non-stick, we recommend using butter or margarine on the outside of the bread, this helps prevent sticking and toasts the sandwiches nicely.

CLEANING AND STORING

1. Before commencing any cleaning, turn the power off at the outlet and remove the power plug.
2. Allow the Sandwich Press to completely cool down first before moving and cleaning.

NOTE: The Sandwich Press is easier to clean when it's still a little warm.

3. Always clean your Sandwich Press after each and every use. This prevents the buildup of foods that have been baked on.
4. Wipe the cooking plates with a soft damp cloth or sponge. As the cooking plates are non-stick, avoid the use of any abrasive cleaners as it will damage the plates. If this fails to remove all residues, soften them with a little oil.
5. Wipe the exterior with a soft damp cloth, do not use any abrasive cleaners.
6. Once the Sandwich Press has cooled completely, store it either flat or upright. Keeping it in its original box is recommended.



WARNING: Do not immerse any part of the Sandwich Press in water or any other liquid.

NOTE: If the supply cord is damaged it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

SPECIFICATIONS

Model	Brand	Description	Voltage	Frequency	Wattage
SP04	HELLER	4 Slice Sandwich Press	220-240Vac	50Hz	1800W

CUSTOMER SERVICE

Australian Customer Service

GAF Control (Sales) Pty Ltd

P.O Box 19

Altona North Victoria 3025

Phone: 1300 659 489

Hours: 9am-5pm (EST) Mon-Fri

www.gafcontrol.com.au

*This product may vary slightly to the product illustrated due to ongoing product development.