


# Directions For Use

Model Number: PGTC

The Tiffany PGTC is suitable for all kinds of peppers and for course salt

1. Open the top cover by turning the top anti-clockwise and load 4 x "AA" batteries into the battery compartment as per the directions marked. (Ensure the plastic sleeve if supplied is fitted over the batteries to retain them in place.)
2. Fit the motor housing to the base by aligning the two metal light wires with the rivets in the top of the base housing and push the motor housing onto the base.
3. Refit the cover to the motor assembly and lock by turning the top clockwise.
4. We recommend that you keep the base jar approximately 80% full for best performance.
5. To select the degree of fineness/coarseness required, the screw under the base should be adjusted as required. If turned fully tight it will provide the finest grind. Adjust the screw to select the desired grind quality
6. If the machine becomes stuck during use, gently shake the unit as the pepper/salt may get stuck in the grinder sometimes. It may be necessary to turn the unit upside down and operate the motor to clear the grinder. This may also be necessary when trying to adjust from a coarse grind to a finer grind.
7. The top button operates the motor and light when pressed and switches off when released.



## Cleaning

Do not allow the unit to come into contact with water or any other liquid.

Wipe the outside of the unit with a damp cloth if necessary.

## Batteries

Operates on 4 x "AA" size batteries.

For best results we recommend the use of alkaline batteries.

