

# HELLER

Instruction Manual

## 50cm Pedestal Fan

Model: HPF55



READ AND SAVE THESE INSTRUCTIONS

Please read and follow the instructions in this user manual even if you feel you are familiar with the product, and find a place to keep it handy for future reference.

For your convenience record the complete model number (located on the product identification plate) and the date you received the product, together with your purchase receipt and attach to the warranty and service information. Retain in the event that warranty service is required.

NOTE: The rating of this product (as marked on the product identification plate) is based on specific loading tests. Normal use or the use of other recommended attachments may draw significantly less power.

## Important Safeguards

**When using any electrically powered product, basic safety precautions should always be followed, including the following:**


PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT

WARNING!: - to reduce the risk of fire, electrical shock or injury to persons or property:

- Always operate the product from a power source of the same voltage, frequency and rating as indicated on the product identification plate.
- Remove the unit from its packaging and check to make sure it is in good condition before using.
- Do not let children play with parts of the packaging (such as plastic bags).
- Close supervision is necessary when the product is used by or near children or infirm persons. Do not allow children to use it as a toy.
- Do not operate any product with a damaged cord or plug, or after the product malfunctions, or is dropped or appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Before unplugging the power cord, be sure to turn the power off. When touching the unit, be sure your hands are dry to prevent electrical shock.
- Avoid making contact with moving parts. Never insert fingers, pencils or any other objects through the guards whenever the power plug is connected, especially while the unit is working.
- Always place the fan on a stable, level surface when operating to prevent the fan from overturning. Do not run the power cord under carpet. Do not cover the power cord with throw rugs or runners. Route the power cord away from walking paths so that nobody can trip over it. The cable should be kept away from heat, sharp edges and oil.
- Metal blades may have sharp edges, so take special care when assembling this product.
- Your pedestal fan should be placed away from heat sources such as; radiators, gas/electric heaters and direct sunlight.
- To reduce the risk of electric shock, do not immerse or expose the product or flexible cord to rain, moisture or any liquid other than those necessary for correct operation of the product.
- This product should not be used in the immediate vicinity of water, such as bathtub, washbowls, bathroom swimming pool etc. Where the likelihood of immersion or splashing could occur.
- Switch off and unplug from outlet when not in use, before assembling or disassembling parts and before cleaning. Remove by grasping the plug - do not pull on the cord.
- Be sure that no other high current appliances are plugged into the same circuit as your fan, as an overload can occur.
- Do not remove any fixed covers.
- Avoid the use of an extension cord as the extension cord may overheat and cause a risk of fire.
- Do not use the appliance for other than its intended use.
- Do not use outdoors. **FOR INDOOR USE ONLY.**
- Do not leave the appliance unattended when switched on.

- Do not cover the grill, or operate in close proximity to curtains etc.
- The use of attachments or accessories not recommended or sold by the product distributor may cause personal or property hazards or injuries.
- Ensure that the fan is switched off from the supply mains before removing the guard.
- This product is intended for normal domestic/household use only.
- Use this fan as described in this manual. Any other uses, not recommended by the manufacturer, may cause fire, electric shock, or injury to persons and may void the warranty.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.

## Parts Location



## Assembly Instructions

Grills, fan blades and the main body of the fan are packed separately to protect your fan from damages during transportation.


1. Attach the column to the stand with the 4 screws as shown.
2. Unscrew and take off the height adjustment nut.
3. Slide the stand cover down the column to rest on the stand.
4. Pull out the extension tube and refit the height adjustment nut.

**Caution:** The height adjustment screw must be fully tightened before assembling the motor section to the pedestal stand.

5. Fit the motor section to the pedestal stand and tighten the thumbscrew.

**Caution:** The thumbscrew must be fully tightened before the fan is operated.

6. Remove the fibre glass sleeve from the shaft and unscrew the rear guard retaining nut by turning it counter-clockwise until tight.
7. Set the rear guard in the proper position (handle uppermost) and screw on the guard retaining nut until tight.
8. Install the blade onto the shaft and screw on the blade retaining nut (counter-clockwise) until tight.
9. Open clips on the front guard and place front guard onto rear guard (align locking screw holes) and close clips.
10. Secure both guards firmly by fitting and tightening the locking screw and nut.



## Before First Use

Before use, remove all packaging and inspect the appliance for any damage. If there appears to be any damage, please take the unit back to place of purchase for a replacement.

## Operating Instructions

*Before inserting the plug into a power outlet, make sure that the correct voltage being used corresponds to what is indicated on the rating label, and that the socket has an earth facility.*

1. Turn the Speed Control knob for the required fan speed: '0' for 'OFF', '1' for Low Speed, '2' for Intermediate Speed and '3' for High Speed.
2. To make the fan head oscillate, push the oscillating knob DOWN. To stop the oscillation, pull the oscillating knob UP.
3. To adjust the tilt of the fan head, simply tilt the fan head to the desired angle. The head can latch in one of three positions.

**CAUTION:** The fan should be switched off when making this adjustment.

**NOTE:** The head will not latch into the low or mid position until the guard and blade are fitted to the motor.

4. To adjust the height of the pedestal fan, loosen the eight adjustment screw carefully raising or lowering the fan and firmly re-tighten the height adjustment nut.

**CAUTION:** The fan should be switched off when making this adjustment.

## Care & Cleaning

To make cleaning easier, you can dismantle some parts of your fan.

- Your appliance must be switched OFF via the main power supply and unplugged before proceeding with any cleaning.
- Clean the housing with a damp cloth, a vacuum cleaner or a dusting brush.
- We recommend lightly running a vacuum cleaner brush nozzle over the fan grill to remove any dust or dirt that may have accumulated.
- Never use flammable or abrasive cleaning agents such as benzene or spirits to clean the appliance.
- Never immerse the appliance in water!

## Specifications

Model	Description	Voltage	Frequency	Wattage
HPF55	50cm Pedestal Fan	220-240V~	50Hz	100W

## Australian Customer Service

GAF Control (Sales) Pty Ltd

P.O Box 19

Altona North Victoria 3025

Phone: 1300 659 489

Hours: 9am-5pm (EST) Mon-Fri

[www.gafcontrol.com.au](http://www.gafcontrol.com.au)

\*This product may vary slightly to the product illustrated due to ongoing product development.