


MAXIM[®]

kitchenpro



Kitchen Scale

Model Number: MKS01

READ AND SAVE THESE INSTRUCTIONS

IMPORTANT

Read and follow the instructions in this user manual even if you feel you are familiar with the product, and find a place to keep it handy for future reference.

For your convenience record the complete model number (located on the product identification plate) and the date you received the product, together with your purchase receipt and attach to the warranty and service information. Retain in the event that warranty service is required.

IMPORTANT SAFEGUARDS

When using any electrically powered product, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT

WARNING!: - to reduce the risk of fire, electrical shock or injury to persons or property:

- Close supervision is necessary when the product is used by or near children or infirm persons. Do not allow children to use it as a toy.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate this product with if the product malfunctions, or appears damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments;
 - Farm houses;
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments.
- Close supervision is necessary when any appliance is used by or near children.
- For protection against electric shock, do not immerse the unit in water or any other liquid.
- The use of accessory attachments not recommended by the appliance manufacturer may cause hazard or injury.
- Do not place on, or near a hot gas or electric burner.
- Not suitable for use outdoors.
- Do not use the appliance other than for its intended use.

FUNCTION SPECIFICATIONS

- ON/OFF/TARE
- Press button 'On' before weighing.
- Four displays (g, kg, oz, lb)
- Will display "HHHH" when the weight overload.
- Low battery will show on LCD display.

OPERATIONS

1. Turn unit ON/OFF/TARE display.
Press the On/OFF/TARE button to start mode changing g → kg → oz → lb.
The default of the mode before each weighing is similar to the last time.
2. Avoid shaking or rocking while weighing items with the scale.
3. When the item weighs greater than 3kgs, press the ON/OFF/TARE button, the LCD will display "TARE" and the screen displays "0". When you take the item away while weighing, it will display a negative number. Press the ON/OFF/TARE button, and "TARE" will disappear.
4. The scale will automatically turn off if there are no operations occurring after 1 minute.
5. When the item weight is overloaded, the LCD display will show "HHHH".

WARRANTY

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The above applies subject to the item not being accidentally dropped by the user-or being used for purposes other than the intended use - or being tampered with. GAF Control (Sales) Pty Ltd guarantees the product for 12 months from date of purchase. Refunds or replacements at retail store level are under the guidance of the stores rules/regulations. In the event of requiring assistance, the retailer from whom you purchased the product should be your first port of call.

Supplier warranting this product:

GAF Control (Sales) Pty Ltd

441 Kororoit Creek Road, Altona

Victoria, 3018, Australia.

12 months warranty from date of purchase. 90 days warranty from date of purchase if used commercially. If your retailer has not validated your guarantee, then retain your purchase receipt. The guarantee does not cover accidental breakage or damage of your product or if it has been tampered with.

Product Model Number: MKS01

Purchase Date: _____

Retailer: _____

Retailer Store Address: _____

Name of Purchaser: _____

Address: _____

Due to the Maxim policy of continual product development; specifications, colours and details of our products as listed or depicted in this user manual or on the product and its carton may differ slightly

Product: Made in China.

To view the full range of Maxim products, please go to our website.

www.gafcontrol.com.au

For additional consumer support – email us at:

gaf@gafcontrol.com.au