

# Tiffany

**1000W Dry Iron**

## **User Manual**

Model Number: DIR88



**READ AND SAVE THESE INSTRUCTIONS**

## IMPORTANT

---

Read and follow the instructions in this user manual even if you feel you are familiar with the product, and find a place to keep it handy for future reference.

For your convenience record the complete model number (located on the product identification plate) and the date you received the product, together with your purchase receipt and attach to the warranty and service information. Retain in the event that warranty service is required.

NOTE: The rating of this product (as marked on the product identification plate) is based on specific loading tests. Normal use or the use of other recommended attachments may draw significantly less power.

## IMPORTANT SAFEGUARDS

---

**When using any electrically powered product, basic safety precautions should always be followed, including the following:**


PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT

WARNING! - to reduce the risk of fire, electrical shock or injury to persons or property:

- Read all instructions before operating the Iron for the first time and save for future reference.
- Always turn the power off at the power outlet before you insert or remove the plug. Remove by grasping the plug – do not pull on the cord.
- Always turn the power off and remove the plug when not in use and before cleaning.
- Always use the iron from a power outlet of the voltage marked on the appliance.
- Do not leave the iron unattended while in use, or when it is plugged into a power outlet.
- Do not leave a hot iron within reach of children. If children come into contact with a hot iron, it could lead to serious burns.
- Use this iron on an ironing board only.
- Do not wind the cord around the iron soleplate while it is still hot.
- An iron takes approximately 30 minutes to cool down. The iron must be completely cooled before storing.
- The iron must be used and rested on a stable surface. If the iron is rested on its stand, ensure the surface is stable.
- Do not use your iron if it has been dropped, if there are visible signs of damage or if it appears to be leaking.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.
- Do not use this appliance for any purpose other than its intended use.
- Do not let the power cord hang over the edge of a bench top or table or touch any hot surface.
- Do not place the appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not use the iron with an extension cord.
- Do not immerse the appliance in water or any other liquid.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- Do not operate any electrical appliance with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or a similarly qualified person.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environment; farm houses; by clients in hotels, motels and other residential type environments; bed & breakfast type environments.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.

## FEATURES

---



## BEFORE FIRST USE

---

- Remove any stickers, plastic covers or cardboard from the soleplate. Ensure that all adhesive is removed from the soleplate before switching the iron on.
- **NOTE:** When the iron is turned on for the first time, it may give off vapours/smells for up to 10 minutes. This is due to the initial heating of the components used. It is safe, and will not affect the performance of the iron, or reoccur.

## USING YOUR IRON

---

1. Before ironing, please make sure the garment can be ironed and follow all instructions provided with the garment.
2. Turn the temperature dial to the '0' position and ensure the iron is rested vertically on a smooth stable surface.
3. Insert the plug in the power outlet and turn the power on.
4. Turn the temperature dial to the desired setting by aligning the setting with the Temperature indicator.
5. After about 1 minute, the indicator light will turn off, when the indicator light turns on again; you are ready to start ironing.
6. After ironing is complete, turn the temperature dial to the '0' position. Pull the plug out of the socket and ensure you allow the iron to completely cool down before storing.

## CLEANING & MAINTENANCE

---

### After Use:

1. Set the temperature dial to '0', and turn the power 'Off' and remove the plug from the power outlet.
2. Allow the iron to completely cool before cleaning or storing.

### Storage:

It is recommended to store the iron on its heel rest if possible. Try not to store the iron with the soleplate facing down.

### Cleaning:

#### **Exterior-**

Wipe the exterior of your iron with a soft damp cloth. **Do Not** use harsh abrasives or solvents, as it will damage the exterior surface.

#### **Non-stick soleplate**

Wipe the soleplate of the iron with a soft damp cloth after each use. To protect the non-stick coating, do not iron over sharp objects, such as buttons and zippers etc. Doing so will scratch the surface. **Do Not** use scourers, abrasives or harsh cleaners on the non-stick soleplate as it will scratch and damage the surface.

## HINTS & TIPS

---

- When selecting the iron temperature, always refer to the garment labels and follow the manufacturer's ironing instructions.
- To save time, sort items to be ironed with similar fabrics, this saves constantly adjusting the temperature. Start with the items that require a cooler setting first, and gradually get warmer.
- If you are unsure of a fabric, and the item doesn't have garment care labels, always test a small area inside the item first. Start with a lower temperature and gradually increase the temperature to find the best heat setting.
- Allow the iron approximately 3 minutes to cool down when reducing the temperature to a cooler setting.
- Fabrics such as Wool, Linen & Silk are best ironed with an ironing cloth to prevent shine marks.
- Do not hang ironed clothes into the wardrobe straight away. Allow clothes to cool completely and then hang them up.

## CUSTOMER SERVICE

---

### **Australian Customer Service**

GAF Control (Sales) Pty Ltd

P.O Box 19

Altona North Victoria 3025

Phone: 1300 659 489

Hours: 9am-5pm (EST) Mon-Fri

**[www.gafcontrol.com.au](http://www.gafcontrol.com.au)**

\*This product may vary slightly to the product illustrated due to ongoing product development.