

RC10A RICE COOKER INSTRUCTION MANUAL

Please read this instruction manual carefully before using your new Tiffany Rice Cooker.

SAFETY PRECAUTIONS FOR YOUR TIFFANY RICE COOKER.

- Do not operate the rice cooker on an inclined surface.
- Do not move or cover the rice cooker while in operation.
- Do not immerse the heating vessel of the rice cooker in water or any other liquid.
- Use your rice cooker at least 200mm away from walls and curtains.
- Do not use your rice cooker in confined spaces.
- Remove the power cord before cleaning the rice cooker.
- After cleaning ensure that the cord inlet area is completely dry before using again.

Please exercise care when using any electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance.

- This product is used for domestic use only.
- Read carefully and save all the instructions provided with an appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug- do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service persons.
- Never leave an appliance unattended while in use.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner.
- Do not immerse the appliance in water or any other liquid unless specified.

FEATURES OF YOUR RICE COOKER.

1. **Non-stick Removable Cooking Pan-** Lightweight pan distributes heat evenly for perfectly cooked rice every time. The non-stick pan is removable for easy cleaning.
2. **Warm Light-** Illuminates to indicate that your Rice Cooker is in the KEEP WARM Mode.
3. **Cook Light-** Illuminates to indicate that the Rice Cooker is in the COOK mode
4. **Glass Lid with Steam Vent-** Allows steam to be released while cooking, reducing condensation.
5. **Cool Touch Handles-** Allows you to lift and carry the Rice Cooker to the table.
6. **Serving Spoon-** Ideal for stirring and serving rice from the rice cooker. The plastic will not scratch the non-stick surface on the cooking pan.
7. **Measuring Cup-** Ensures the accurate measuring of rice to achieve perfect results every time.

USING YOUR RICE COOKER.

1. Before using your Rice Cooker for the first time wash the cooking pan, lid, measuring cup and serving spoon in warm soapy water. Rinse and dry thoroughly.
2. Using the measuring cup provided, measure out the required quantity of rice.
3. Using a sieve, wash rice thoroughly under cold water before cooking. This removes excess starch which helps to achieve fluffier rice. Make sure water runs clear before use. **Note:** A fine mesh sieve is the most effective way to wash the rice. Run water through rice until water runs clear not milky. Alternatively, wash the rice in the cooking pan two or three times until the water is clear, pouring out the milky water in between each rinse, taking care not to tip the rice out with the water.
4. Ensuring that the exterior of the cooking pan is clean and dry, place it inside the heating vessel.
5. Place the washed rice in the removable pan. Add cold water to the cup level indicated on the inside of the removable pan or quantity of water specified.
6. Replace the lid.
7. Insert the plug into a 220-240 volt AC power outlet and turn the power on.
8. Press the control lever to "COOK" to begin the cooking cycle. The "COOK" light will illuminate.
9. When cooking is complete, your rice cooker will automatically switch to "WARM" mode and the "WARM" light will illuminate.
10. Allow rice to stand in the "WARM" mode for 5-10 minutes for small quantities and approximately 10-15 minutes for larger quantities, with the lid on. DO NOT use metal utensils as these will scratch the non-stick coating. A plastic spoon is supplied.
11. The "WARM" cycle will continue until the power is switched off. If keeping the rice warm, stir, then replace lid.
Note: During the operating- do not remove the lid as this may affect cooking results. Do not interfere with the automatic control lever. Do not keep rice in the cooker for extended periods of time on "WARM" mode as the rice becomes dry and the quality deteriorates.

CARE AND CLEANING.

After using your rice cooker, turn the power off and remove the cord from the power outlet. The lid, removable pan, measuring cup and serving spoon should be washed in warm water using a mild detergent. **DO NOT** use harsh abrasives to clean the removable cooking pan as these will damage the non-stick coating. The exterior of the cooking vessel can be wiped over with a damp cloth.

CAUTION: Never immerse the heating vessel in water.

DO NOT place any part of your Rice Cooker in a dishwasher. The hot water temperatures and harsh detergents may warp or stain the parts.

CAUTION: Never use any chemical, steel wool, harsh abrasive cleaners, thinners or chemical dust cloths to clean any part of your Rice Cooker.

WARNING: Do not allow water to enter the inside of the heating vessel as this may cause electrocution.

Tiffany

10 Cup Rice Cooker

Instruction Booklet RC10A



Please read these instructions carefully and retain for future reference.