




## USER MANUAL

Model Number: CR299

### LOCATION OF CONTROLS:

1. ON / OFF/Auto Function Switch
2. Alarm Set Button
3. Sleep Set Button
4. Hour Set Button
5. Minute Set Button
6. Time Set Button
7. Snooze Button
8. Alarm Indicator
9. Tuning Control
10. Tuning Scale
11. Buzzer/Volume Control
12. Wave Band Selector



### POWER SUPPLY:

Always operate the product from a power source of the same voltage, frequency and rating as indicated on the product identification plate. Once plugged in a blinking signal will appear indicating the time.

### LISTENING TO THE RADIO:

Slide the Function Switch to the "On" position. Adjust the buzzer/ volume control to the desired noise level and select your desired station with the tuning control and the wave band selector. To turn the radio off, slide the function switch to the "Off" position.

### SETTING THE TIME:

Press and hold the time set button and then press the hour set button or minute set button for hour and minute time adjustment. Please make sure the setting time is AM or PM (A dot will light up in the upper left corner indicating that the time is in the PM range - if your unit is a 12 hour version).

### WAKE UP TO MUSIC:

Press and hold the alarm button and then press the hour or minute button to set the desired wake up time. Release the alarm button to show the current time. The alarm indicator will light up. Repeat the steps of "Listening to the radio" to set your desired station and noise level. Slide the function switch to the "Auto" position. The radio will play your desired station and noise level automatically at the preset alarm time.

**WAKE UP TO A BUZZER:**

Waking up to a buzzer is the same operation as “Wake up to music”. Adjust the alarm time, and then rotate the volume control clockwise until a clicking sound is heard. You will be awakened by the buzzer alarm.

**SNOOZE FUNCTION:**

When you want a few extra minutes of sleep after the alarm wakes you, press the Snooze Button. The music or buzzer alarm will be off and automatically turn on again in 9 minutes. Push the function switch to “Off” to turn off the snooze function.

**SLEEP TO MUSIC:**

1. Slide the Function Switch to either the “Off” or “Auto” position. Press the sleep button once and you will have 59 minutes to listen to the radio (default setting) before switching itself off.
2. If you want to increase or reduce the automatic turn off time, hold down the sleep button, and press the minute set button to adjust as required.

**TO GO TO SLEEP AND WAKE UP TO MUSIC:**

Repeat the steps of “Wake up to music”, and then press the sleep button to set the desired time of music playing before you sleep. The radio will stop automatically and will play again at your preset wake up time.

**BATTERY BACKUP:**

Insert a 9 volt battery in the battery compartment. Should there be a power failure the clock will continue to function. The battery does not illuminate the clock display. When the power turns on again, the display will show the correct time. The alarm clock does not work whilst powered by the battery. It is recommended that you replace the battery once a year.

**SPECIFICATIONS:**

Power Source : 240V ~ 50Hz

Frequency Range : AM 540 ~ 1600KHz ; FM 88 ~ 108MHz

Time Backup : 1pc x 9V dry battery (not included)

**WARNINGS:**

- The ventilation openings should not be covered with items, such as newspapers, table-cloths, curtains, etc;
- No naked flame sources, such as candles, should be placed on or near the product;
- It should not be exposed to splashing or water and no objects filled with liquid, such as vases, shall be placed on or near the product;
- Do not place the product in closed bookcases or racks without proper ventilation.

GAF Control (Sales) Pty Ltd  
Po Box 19  
Altona North  
Vic 3025